



## Greenhouse Plastic Repair Tape Instructions

- 1) Begin by cleaning the repair area with isopropyl alcohol to remove any dirt or body oils which may prevent a good bond.
- 2) Cut a piece of tape that will extend past the repair area by several inches on each side. The width of the tape should extend at least 1" past the repair area on each side. If the tape is not wide enough to do this, add a 2<sup>nd</sup> piece of repair tape to increase the width of the patched area as show below. Repeat if needed.



- 3) Smooth out any bubbles and ensure the edges lay flat. The adhesive will reach full strength after 24 hours.
- 4) For large holes, repeat the above steps on the opposite side of the plastic.
- 5) If you applying patching tape in temperatures below 60°F, it is recommended you heat the area where the tape was applied with a hair dryer or heat gun to ensure a proper bond to the plastic.